

1                                   **SECTION 602 – REINFORCING STEEL**  
2

3    Make the following amendment to said Section:  
4

5    **(I) Amend Section 602.03(D) – Placing and Fastening** by adding following  
6    paragraph after line 114 to read:  
7

8            “Welded-wire fabric must not be laid on the ground and “pulled up” after  
9            the concrete is placed or “walked in” after placing the concrete or using  
10           small piles of fresh concrete. Use supports tied to the WWF, e.g. precast  
11           concrete spacer blocks to maintain the proper elevation of the WWF.  
12           Plastic spacers must not be used. The number of precast concrete spacer  
13           blocks must be used in a quantity that will prevent sagging, bending, or  
14           when walked upon, and still, maintain the required clearances.”  
15

16  
17                                   **END OF SECTION 602**  
18