

SECTION 613 – CENTERLINE AND REFERENCE SURVEY MONUMENTS

Make the following amendment to said Section:

(I) Amend **Subsection 613.03(A) – Initial Installation** from lines 22 to 26 to read:

“(A) Initial Installation. Cut holes, in completed medians and shoulders, to required depth or to solid rock, whichever is less. Fill hole with concrete. Burr or feather plug for anchorage in concrete. Place the 4 #4 x 20-inch bars as shown on the plans when curing the concrete. Install brass plug in required position after concrete has sufficiently set. After curing concrete at least 7 days, restore edge of pavement surrounding monument to original condition.”

END OF SECTION 613