

1                                   **SECTION 602 – Reinforcing Steel**  
2

3   Make the following amendments to said Section:  
4

5   **(I)**     Amend **602.03(D) – Placing and Fastening** by Adding the following  
6   paragraph after line 114 to read:  
7

8           "Welded-wire fabric must not be laid on the ground and "pulled up" after the  
9   concrete is placed or "walked in" after placing the concrete or using small  
10   piles of fresh concrete. Use supports tied to WWF, e.g. precast concrete  
11   spacer blocks to maintain the proper elevation of the WWF. Plastic spacers  
12   must not be used. The number of precast concrete spacer blocks must be  
13   used in a quantity that will prevent sagging, bending, or when walked upon,  
14   and still, maintain the required clearances."  
15  
16  
17  
18  
19

20                                   **END OF SECTION 602**