

SECTION 602 – Reinforcing Steel

Make the following amendments to said Section:

(I) Amend 602.03(D) – Placing and Fastening by Adding the following paragraph after line 114 to read:

“Welded-wire fabric must not be laid on the ground and “pulled up” after the concrete is placed or “walked in” after placing the concrete or using small piles of fresh concrete. Use supports tied to WWF, e.g. precast concrete spacer blocks to maintain the proper elevation of the WWF. Plastic spacers must not be used. The number of precast concrete spacer blocks must be used in a quantity that will prevent sagging, bending, or when walked upon, and still, maintain the required clearances.”

END OF SECTION 602