1	SE	CTION 613 - CENTERLINE AND REFERENCE SURVEY MONUMENTS
2 3	Make	the following amendment to said Section:
4	/I\	Amond Subsection 642 02(A) Initial Installation from lines 22 to 26 to
5	(I)	Amend Subsection 613.03(A) - Initial Installation from lines 22 to 26 to
6 7	read:	
8		"(A) Initial Installation. Cut holes, in completed medians and
9		shoulders, to required depth or to solid rock, whichever is less. Fill hole
10		with concrete. Burr or feather plug for anchorage in concrete. Place
11		the 4 #4 x 20-inch bars as shown on the plans when curing the concrete.
12		Install brass plug in required position after concrete has sufficiently set.
13		After curing concrete at least 7 days, restore edge of pavement
14		surrounding monument to original condition."
15		
16		
17		
18		
19		END OF SECTION 613