

1 **SECTION 613 – CENTERLINE AND REFERENCE SURVEY MONUMENTS**

2
3 Make the following amendments to said Section:

4
5 **(I)** Amend **Subsection 613.03(A) – Initial Installation** from lines 22 to 26 to
6 read:

7
8 **“(A) Initial Installation.** Cut holes, in completed medians and
9 shoulders, to required depth or to solid rock, whichever is less. Fill hole
10 with concrete. Burr or feather plug for anchorage in concrete. Place
11 the 4 #4 x 20-inch bars as shown on the plans when curing the concrete.
12 Install brass plug in required position after concrete has sufficiently set.
13 After curing concrete at least 7 days, restore edge of pavement
14 surrounding monument to original condition.”

15
16
17
18 **END OF SECTION 613**